


### **TURNING THE HANDSET ON**

Press the  button for 1 second.


When the handset is turned on the  symbol is shown in the lower left corner of the display, if the handset is subscribed to a system.



### **TURNING THE HANDSET OFF**

Press the  button for 4 seconds.

Note: When the handset has been outside the coverage area, it can take up to 30 seconds before the handset is back on the system after re-entering the coverage area.


### **MAKING A CALL**



For making or receiving calls the handset has to be subscribed to a system  (shown in display).

Press the  button, the  icon in the display will flash until the connection is established.




Dial the number onto the keypad.



#### **Pre-dial:**

Dial the number onto the keypad (long press on the  button will make a pause, if necessary).


Press the  button, the  icon will flash until the connection is established.

#### **Telephone book:**


Press the  (BOOK) to enter the telephone book. Search for the number either by using the  or  buttons or by pressing the first letter in the name by using the digits 1 - 9.


Press the  button, the  icon will flash until the connection is established.

### **ANSWERING/ENDING A CALL**





To answer a call, press the  button.


### **KEY LOCK**

To lock the handset keypad to prevent accidental button presses, press the **MENU** button then the  button.

To unlock the handset keypad, press the **MENU** button and then the  button again.

### **PROFILE SETUP**

The handset has a user-defined profile and a mode where all sounds are disabled (SILENT). Pressing the **MENU** button then the  button will enter the profile setup where you can configure the following various handset functions: backlight, ring tone, ringer volume, key click, vibrator, b-answer, start volume, out of range indicator and auto key lock. To access these functions use the  or  buttons and then the  button.

The handset also has a silent function. Pressing the **MENU** button then the  will toggle the SILENT mode. The display shows SILENT if the SILENT mode is chosen.

### **HOLD**

To place a caller on hold, press the **R** button.

To retrieve the call, press **R** twice.

### **TRANSFER**

Press **R** button then dial the extension or outside number to where you wish to transfer the call. Wait for ring tone or for the party to answer, and then hang up to send the call through. If your party does not wish to take the call, wait until they hang up and you will get the caller back automatically.



**Note:** Should you wish to go back to a caller because you have reached someone's voice mail, you will need to press the **R** button twice to drop the voice mail and return to the caller.

### **3 - WAY CONFERENCE**

The handset registered onto a Cisco Call Manager can be included in a conference call, only if the conference originates from a Cisco IP system and analogue phones.


### **MUTE**


You may turn the microphone off during a conversation.

By pressing the  button (display will show MIC. MUTED). To turn the microphone back on, press the  button again (display goes blank).

### **CALL FORWARD ALL**

Enables you to send calls to another extension.

To set, dial **\*\*1**, wait for a confirmation, then enter the extension number where you want your calls to ring and then press the  button.

To cancel your forwarding, dial **\*\*2** and then press the  button.





### **CALL FORWARD BUSY**

To set, please contact the system administrator as call forward busy can only be configured via the Cisco Call Manager administration console.

### **CALL FORWARD NO ANSWER**

To set, please contact the system administrator as call forward no answer can only be configured via the Cisco Call Manager administration console.

### **LAST NUMBER REDIAL**

To dial the last number you called, press the  button and scroll using the  or  button to select the desired number and then press the  button.

### **CALL PICKUP**

Enables you to pickup a incoming call ringing at another extension which is a member of the same pickup group.

To perform call pickup, dial **\*\*3** and then press the  button.